

Report from Radionics models D7112,D9112:

<b>Signal</b>	<b>SG-DRL2A Print out</b>	<b>Automation output</b>
Fire Alarm	L0X-AAA-FIRE ALARM-----	6RRLsssssssAAAsFssszt
Fire Trouble	L0X-AAA-FIRE TROUBLE----	6RRLsssssssAAAGsssszt
Fire Missing	L0X-AAA-FIRE TROUBLE ---	6RRLsssssssAAAsGsssszt
Fire Restoral After Alarm	L0X-AAA-FIRE RESTORAL---	6RRLsssssssAAAHsssszt
Fire Restoral After Trouble	L0X-AAA-ALARM REPORT----	6RRLsssssssAAAHsssszt
Fire Walk Start	L0X-AAA-FIRE TROUBLE-----	6RRLsssssssAAAsTsssFt
Fire Walk End	L0X-AAA-FIRE RESTORAL-----	6RRLsssssssAAAsRsssFt
Alarm	L0X-AAA- ALARM -----	6RRLsssssssAAAsAssszt
Duress	L0X-AAA- ALARM-----	6RRLsssssssAAAsAssszt
User Alarm 7	L0X-AAA-ALARM-----	6RRLsssssssAAAsAssszt
User Alarm 9	L0X-AAA-ALARM-----	6RRLsssssssAAAsAssszt
Cancel Alarm by Area	L0X-AAA-CANCEL REPORT---	6RRLsssssssAAAs\sssst
Trouble	L0X-AAA-TROUBLE-----	6RRLsssssssAAAsTssszt
Restoral	L0X-AAA-POINT OPENING---	6RRLsssssssAAAsRssszt
Missing Alarm	L0X-AAA-ALARM-----	6RRLsssssssAAAsAssszt

Missing trouble	L0X-AAA-TROUBLE-----	6RRLsssssssAAAstsszt
Early Open by Account	L0X-AAA-OPENING ZN i----	6RRLsssssssAAAsOsssit
Early Open by Account (no ID) area	L0X-AAA-OPENING REPORT-	6RRLsssssssAAAsOsssst
Early Open by Area	L0X-AAA-OPENING ZN z---	6RRLsssssssAAAsOssszt
Opening by Account	L0X-AAA-OPENING ZN i---	6RRLsssssssAAAsOsssit
Opening by Account (no ID)	L0X-AAA-OPENING REPORT	6RRLsssssssAAAsOsssst
Opening by Area	L0X-AAA-OPENING ZN z-	6RRLsssssssAAAsOssszt
Late Open by Account	L0X-AAA-OPENING ZN i-	6RRLsssssssAAAsOsssit
Late Open By Account(no ID)	L0X-AAA-OPENING REPORT-	6RRLsssssssAAAsOsssst
Late Open by Area	L0X-AAA-OPENING ZN z-	6RRLsssssssAAAsOssszt
Closing Early by Account	L0X-AAA-CLOSING ZN i----	6RRLsssssssAAAsCsssit
Closing Early by Account(no ID)	L0X-AAA-CLOSING REPORT-	6RRLsssssssAAAsCsssst
Closing Early by Area	L0X-AAA-CLOSING ZN z---	6RRLsssssssAAAsCssszt
Force Close Early by Account	L0X-AAA- CLOSING ZN i---- WAS FORCE ARMED	6RRLsssssssAAAsCsssit 6RRLsssssssAAAsWsssst
Force Close Early by Account(no id)	L0X-AAA- CLOSING REPORT---- WAS FORCE ARMED	6RRLsssssssAAAsCsssst 6RRLsssssssAAAsWsssst
Force Close Early by Area	L0X-AAA- CLOSING ZN z---- WAS FORCE ARMED	6RRLsssssssAAAsCssszt 6RRLsssssssAAAsWsssst
Closing by Account	L0X-AAA-CLOSING ZN i-----	6RRLsssssssAAAsCsssit
Closing by Account(no ID)	L0X-AAA-CLOSING REPORT---	6RRLsssssssAAAsCsssst

Closing by Area	L0X-AAA-CLOSING ZN z-----	6RRLsssssssAAAsCssszt
Force Closing by Account	L0X-AAA- CLOSING ZN i---- WAS FORCE ARMED	6RRLsssssssAAAsCsssit 6RRLsssssssAAAsWsssst
Force Closing by Account(no ID)	L0X-AAA- CLOSING REPORT---- WAS FORCE ARMED	6RRLsssssssAAAsCsssst 6RRLsssssssAAAsWsssst
Closing Late by Account	L0X-AAA-CLOSING ZN i--	6RRLsssssssAAAsCsssit
Closing Late by Account(no ID)	L0X-AAA-CLOSING REPORT--	6RRLsssssssAAAsCsssst
Force Closing by Area	L0X-AAA- CLOSING ZN z---- WAS FORCE ARMED	6RRLsssssssAAAsCssszt 6RRLsssssssAAAsWsssst
Closing Late by Area	L0X-AAA-CLOSING REPORT--	6RRLsssssssAAAsCsssst
Force Close Late by Account	L0X-AAA- CLOSING ZN i---- WAS FORCE ARMED	6RRLsssssssAAAsCsssit 6RRLsssssssAAAsWsssst
Force Close Late by Account(no ID)	L0X-AAA- CLOSING REPORT--- WAS FORCE ARMED	6RRLsssssssAAAsCsssst 6RRLsssssssAAAsWsssst
Test Report	L0X-AAA-RESTORAL ZN E ----	6RRLsssssssAAAsRsssEt
Status: Alarm	L0X-AAA-STATUS REPORT --- ALARM ZN z	6RRLsssssssAAAsSsssst 6RRLsssssssAAAsAssszt
Status: Trouble	L0X-AAA-STATUS REPORT --- TROUBLE ZN z	6RRLsssssssAAAsSsssst 6RRLsssssssAAAsTssszt
Status: Open by Area	L0X-AAA-STATUS REPORT --- OPENING ZN z	6RRLsssssssAAAsSsssst 6RRLsssssssAAAsOssszt
Status: Close by Area	L0X-AAA-STATUS REPORT --- CLOSING ZN z	6RRLsssssssAAAsSsssst 6RRLsssssssAAAsCssszt
Status: Perimeter Instant by Area	L0X-AAA-STATUS REPORT --- OPENING ZN z	6RRLsssssssAAAsSsssst 6RRLsssssssAAAsOssszt
Status: Perimeter Delay by Area	L0X-AAA-STATUS REPORT --- OPENING ZN z	6RRLsssssssAAAsSsssst 6RRLsssssssAAAsOssszt
Swinger Bypass	L0X-AAA-TROUBLE ZN z-	6RRLsssssssAAAsTssszt
Command Bypass	L0X-AAA-TROUBLE ZN z-	6RRLsssssssAAAsTssszt

Point Bypass	L0X-AAA-TROUBLE ZN z-	6RRLsssssssAAAsTssszt
Sked Bypass	L0X-AAA-TROUBLE ZN z-	6RRLsssssssAAAsTssszt
Prgr Bypass	L0X-AAA-TROUBLE ZN z-	6RRLsssssssAAAsTssszt
Remote Bypass	L0X-AAA-TROUBLE ZN z-	6RRLsssssssAAAsTssszt
Force Point	L0X-AAA-TROUBLE ZN z-	6RRLsssssssAAAsTssszt
Valid Remote Access	L0X-AAA-RESTORAL ZN F-	6RRLsssssssAAAsTsssFt
Invalid Remote Access	L0X-AAA-TROUBLE ZN F-	6RRLsssssssAAAsTsssFt
Fail to Call RAM	L0X-AAA-TROUBLE ZN F-	6RRLsssssssAAAsTsssFt

<b>Signal</b>	<b>DRL2A Print Out</b>	<b>Automation Output</b>
Phone Line 1 Fail	L0X-AAA-TROUBLE ZN B---	IRRLsssssssAAAsTsssbt
Phone Line 2 Fail	L0X-AAA-TROUBLE ZN C---	IRRLsssssssAAAsTsssCt
Phone Line 1 Restoral	L0X-AAA-RESTORAL ZN B---	IRRLsssssssAAAsRsssBt
Phone Line 2 Restoral	L0X-AAA-RESTORAL ZN C---	IRRLsssssssAAAsRsssCt
SDI Fail	L0X-AAA-TROUBLE ZN D---	IRRLsssssssAAAsTsssDt
SDI Restoral	L0X-AAA-RESTORAL ZN D---	IRRLsssssssAAAsRsssDt
Point Bus Fail	L0X-AAA-TROUBLE ZN D---	IRRLsssssssAAAsTsssDt
Point Bus Restoral	L0X-AAA-RESTORAL ZN D---	IRRLsssssssAAAsRsssDt
AC Fail (as a rider)	L0X-AAA-AC FAILED---	IRRLsssssssAAAsPsssst
AC Fail	L0X-AAA-TROUBLE ZN z--	IRRLsssssssAAAsTssszt
AC Restoral	L0X-AAA-RESTORAL ZN z--	IRRLsssssssAAAsRssszt
Battery Missing	L0X-AAA-TROUBLE ZN z--	IRRLsssssssAAAsTssszt
Battery Low	L0X-AAA-TROUBLE ZN z--	IRRLsssssssAAAsTssszt
Battery Restoral	L0X-AAA-RESTORAL ZN z--	IRRLsssssssAAAsRssszt
Watchdog Reset	L0X-AAA-RESTORAL ZN 9--	IRRLsssssssAAAsRsss9t
Remote Restoral	L0X-AAA-RESTORAL ZN 9--	IRRLsssssssAAAsRsss9t
Re-Boot	L0X-AAA-RESTORAL ZN z--	IRRLsssssssAAAsRsss9t

Transmitter Tamper Restoral	L0X-AAA-RESTORAL ZN z--	1RRLsssssssAAAsRssszt
Transmitter Low Battery	L0X-AAA-TROUBLE ZN z--	1RRLsssssssAAAsTssszt
Transmitter Battery Restoral	L0X-AAA-RESTORAL ZN z--	1RRLsssssssAAAsRssszt
Transmitter Tamper Alarm	L0X-AAA-ALARM ZN z--	1RRLsssssssAAAsAssszt
Transmitter Tamper Trouble	L0X-AAA-TROUBLE ZN z--	1RRLsssssssAAAsTssszt
Alarm No Zone Reported	L0X-AAA-ALARM REPORT--	1RRLsssssssAAAsAsssst
Alarm 0 - F	L0X-AAA-ALARM ZN z--	1RRLsssssssAAAsAssszt
Alarm 100 - 816	L0X-AAA-ALARM ZN zyy--	1RRLsssssssAAAsAszyyt
Missing Alarm 101 - 816	L0X-AAA-ALARM ZN zyy--	1RRLsssssssAAAsAszyyt
Alarm 10 - 15	L0X-AAA-ALARM ZN xx	1RRLsssssssAAAsAssxxt
Alarm 16	L0X-AAA-ALARM ZN 16--	1RRLsssssssAAAsAss16t
Status Rpt/Alarm	L0X-AAA-ALARM ZN z--	1RRLsssssssAAASAssszt
Fire Alarm 0 - 9	L0X-AAA-FIRE FR z--	1RRLsssssssAAAsFssszt
User Alarm 0 - 9	L0X-AAA-USR ALRM ZN z--	1RRLsssssssAAAsUssszt
Duress 0 - F	L0X-AAA-DURESS ID z--	1RRLsssssssAAAsDssszt
Diagnostic No Zone Reported	L0X-AAA-DIAG REPORT--	1RRLsssssssAAAsYssszt
Diagnostics 0 - F	L0X-AAA-DIAG ZN z--	1RRLsssssssAAAsYssszt

A MEMBER OF THE DSC GROUP **DSC** ***BFSK Format Library- From Other Control/Communicators***

Trouble No Zone Reported	L0X-AAA-TROUBLE REPORT--	1RRLsssssssAAAsTsssst
Trouble 0 -F	L0X-AAA-TROUBLE ZN z--	1RRLsssssssAAAsTssszt
Trouble 100 - 816	L0X-AAA-TROUBLE ZN zyy--	1RRLsssssssAAAsTszyyt
Missing Trouble 101 - 816	L0X-AAA-TROUBLE ZN zyy--	1RRLsssssssAAAsTszyyt
Trouble 10 - 15	L0X-AAA-TROUBLE ZN xx--	1RRLsssssssAAAsTssxxt
Trouble 16	L0X-AAA-TROUBLE ZN 16--	1RRLsssssssAAAsTss16t
Status Rpt/Trouble	L0X-AAA-TROUBLE ZN z--	1RRLsssssssAAASTssszt
Fire Trouble 0 - 9	L0X-AAA-TROUBLE FR z--	1RRLsssssssAAAGsssszt
Shunted 1 - 8	L0X-AAA-SHUNTED ZN z--	1RRLsssssssAAAsNssst
Shunted 100 - 816	L0X-AAA-SHUNTED ZN zyy--	1RRLsssssssAAAsNszyyt
Restoral No Zone Reported	L0X-AAA-RESTORAL REPORT--	1RRLsssssssAAAsRsssst
Restoral 0 -F	L0X-AAA-RESTORAL ZN z--	1RRLsssssssAAAsRssszt
Restoral 100 - 816	L0X-AAA-RESTORAL ZN zyy--	1RRLsssssssAAAsRszyyt
Missing Restoral 101 - 816	L0X-AAA-RESTORAL ZN zyy--	1RRLsssssssAAAsRszyyt
Restoral 10 - 15	L0X-AAA-RESTORAL ZN xx--	1RRLsssssssAAAsRssxxt
Restoral 16	L0X-AAA-RESTORAL ZN 16--	1RRLsssssssAAAsRss16t
Status No Zone Reported	L0X-AAA-RESTORAL REPORT--	1RRLsssssssAAASRsssst

Status Rpt/Restoral	L0X-AAA-RESTORAL ZN z--	1RRLssssssAAASRssszt
Restoral Fire 0 - 9	L0X-AAA-RESTORAL FR z--	1RRLssssssAAAHssszt
Opening No Zone Reported	L0X-AAA-OPENING REPORT--	1RRLssssssAAAsOsssst
Opening 0 - F	L0X-AAA-OPENING ZN i--	1RRLssssssAAAsOsssit
Opening 0 - 7	L0X-AAA-OPENING ID i--	1RRLssssssAAAsOsssit
Opening 601 - F08	L0X-AAA-OPENING ID iyy--	1RRLssssssAAAsOsiyyt
Status Rpt/Opening	L0X-AAA-OPENING REPORT--	1RRLssssssAAASOsssst
Status Rpt/Opening	L0X-AAA-OPENING ID i--	1RRLssssssAAASOsssit
Closing No Zone Reported	L0X-AAA-CLOSING REPORT--	1RRLssssssAAAsCsssst
Closing 0 - F	L0X-AAA-CLOSING ZN i--	1RRLssssssAAAsCsssit
Closing 0 - 7	L0X-AAA-CLOSING ID i--	1RRLssssssAAAsCsssit
Closing 601 - F08	L0X-AAA-CLOSING ID iyy--	1RRLssssssAAAsCsiyyt
Status Rpt/Closing	L0X-AAA-CLOSING REPORT--	1RRLssssssAAASCsssst
Status Rpt/Closing	L0X-AAA-CLOSING ID i--	1RRLssssssAAASCsssit
Cancel No Zone Reported	L0X-AAA-CANCEL REPORT--	1RRLssssssAAAs\sssst
Cancel 0 - F	L0X-AAA-CANCEL ID i--	1RRLssssssAAAs\sssit
Cancel 601 - F08	L0X-AAA-CANCEL ID iyy--	1RRLssssssAAAs\siyyt



Power Fail	L0X-AAA-AC FAIL--	1RRLsssssssAAAsPsssst
Was Forced Armed	L0X-AAA-WAS FORCED ARM--	1RRLsssssssAAAsWsssst
Status Report	L0X-AAA-STATUS REPORT--	1RRLsssssssAAAsSsssst
Status Rpt/Power Fail	L0X-AAA-AC FAIL--	1RRLsssssssAAASPsssst
Listen In	L0X-AAA-LISTEN IN--	1RRLsssssssAAAs*sssst
Listen In	L0X-AAA-LISTEN IN--	1RRLsssssssAAAs*sssst
Listen Done	L0X-AAA-LISTEN DONE--	1RRLsssssssAAAsLsssst